



Part PJDI095: D07RE5 - 3 GPM Injection Seal Kit

This kit contains:


(1) J029	Plunger seal
(1) PDI550	Injection sleeve key
(1) J051	Check valve seal
(1) MPDI122	Check valve assembly
(1) JDI092	Injection stem o-ring
(1) P169	Check valve barb
(1) 8J026	Injection sleeve o-ring




Vea el reverso para instrucciones en Español.

2090 Sunnydale Blvd.
Clearwater, FL 33765
800-523-8499 • 727-443-5404
www.dosatronusa.com

3. Unscrew the check valve barb (**P169**), remove the check valve seal (**J051**), unscrew the locking nut (**P168**), remove the anti-lock ring (**P189**), and remove the check valve assembly (**MPDI122**) from the stem.



4. Unscrew and remove the adjusting sleeve (**PDI549**). With the help of a small flat head screwdriver remove the plastic injection sleeve key (**PDI550**) located inside the lower part of the injection sleeve (**PDI538**). Remove the injection stem (**PDI539**) from the bottom of the injection sleeve (**PDI538**). Replace the injection stem o-ring (**JDI092**) and injection sleeve o-ring (**8J026**).



Kit Contents:

P169: Check valve barb



8J026: Injection sleeve o-ring



MPDI122: Check valve assembly



PDI550: Injection sleeve key



J051:
Check valve seal



J029:
Plunger seal



JDI092: Injection stem o-ring




! We recommend cleaning all parts with warm soapy water and a toothbrush before installing the new parts. Water normally lubricates the parts, but you may use silicone on the o-ring to facilitate insertion. Check valve may be taken apart and cleaned in between maintenance to remove particles.

STOP CAUTION: Parts may contain concentrated chemicals. The use of Proper Protective Equipment is recommended when performing maintenance.

Instructions


(Parts included in kit noted in blue)

- Unscrew suction hose nut (**P153**) and remove suction hose.




- Unscrew and remove injection stem assembly (**CDDI066**).

NOTE: If the adjusting sleeve (**PDI549**) starts to unscrew, tighten the locking nut (**P168**) at the bottom and the injection stem assembly will unscrew.




! Using tools could damage the plunger and affect the injection rate


5. Insert the injection stem (**PDI539**) into the bottom part of the injection sleeve (**PDI538**). Make sure that the long groove in the injection stem aligns with the hole in the lower part of the injection sleeve. With the help of a small flat head screwdriver install the new plastic injection sleeve key (**PDI550**) all the way into the injection sleeve (**PDI538**). Thread the adjusting sleeve (**PDI549**) onto the injection sleeve (**PDI538**) until it reaches the top of the scale.



6. Reinstall the anti-lock ring (**P189**) and the locking nut (**P168**). Insert new check valve assembly (**MPDI122**) into the injection stem with the cone pointing out. Position the check valve seal (**J051**) onto the new check valve barb (**P169**) with the groove facing up. Thread the new check valve barb.



7. Replace the plunger seal (**J029**). Thread the injection stem assembly (**CDDI066**) into the body. Slide suction hose nut (**P153**) onto the suction hose, reattached suction hose onto check valve barb and tighten suction hose nut (**P153**).



! To ensure hose is air-tight, you may choose to carefully cut the top of hose before reinserting.

! REMEMBER TO RESET YOUR INJECTION RATE TO THE PROPER RATIO

Contenido del Kit:

P169: Lengüeta de la válvula cheque



8J026: O-ring de la manga de inyección



MPDI122: Válvula cheque



PDI550: Llave de la manga de inyección



J051: Sello de la válvula cheque




J029: Empaque del embolo




JDI092: O-ring de la barra de inyección



- Desatornille la lengüeta de la válvula cheque (**P169**), remueve el sello de la válvula cheque (**J051**), desatornille la tuerca de seguridad (**P168**), remueve el anillo antibloqueo (**P189**), y remueve la válvula cheque (**MPDI122**) de la barra.



- Desatornille y remueva la manga de ajuste (**PDI549**). Con la ayuda de un destornillador pequeño de cabeza plana remueve la llave plástica de la manga de inyección (**PDI538**) ubicada dentro de la parte inferior de la manga de inyección (**PDI539**). De la parte inferior remueve también la barra de inyección (**PDI539**). Reemplace el o-ring de la barra de inyección (**JDI092**) y el o-ring de la manga de inyección (**8J026**).



! El uso de herramientas podría dañar el embolo y afectar el índice de inyección.

! Recomendamos limpiar todas las partes con agua tibia jabonosa y un cepillo de dientes antes de instalar las partes nuevas.

El agua normalmente lubrica las partes, pero usted puede usar silicona sobre el o-ring para facilitar la inserción.

La válvula cheque se puede desarmar y limpiar entre mantenimientos para remover las partículas.

! Para asegurarse que la manguera este firmemente ajustada, puede cortar la punta de la manguera antes de insertarla.



! NO OLVIDE REAJUSTAR SU INDICE DE INYECCION A LA PROPORCIÓN ADECUADA.

STOP PRECAUCIÓN: Las partes pueden contener químicos concentrados. El uso de Equipo de Protección Adecuado es recomendado cuando se efectúa el mantenimiento.

Instrucciones



(Partes en color azul incluidas en el kit)

- Desatornille la tuerca de la manguera de succión (**P153**) y remueva la manguera.




- Desatornille y remueva el montaje de inyección (**CDDI066**).


NOTA: Si la manga de ajuste (**PDI549**) comienza a desatornillarse, apriete la tuerca de seguridad (**P168**) en la parte inferior y el montaje de inyección se desatornillara.



- Reinstale el anillo antibloqueo (**P189**) y la tuerca de seguridad (**P168**). Inserte la nueva válvula cheque (**MPDI122**) dentro de la barra de inyección con el cono apuntando hacia afuera.



- Coloque el sello de la válvula cheque (**J051**) sobre la nueva lengüeta de la válvula cheque (**P169**) con la ranura hacia arriba. Atornille la nueva lengüeta de la válvula cheque.



- Remplace el empaque del embolo (**J029**). Atornille el montaje de inyección (**CDDI066**) dentro del cuerpo. Deslice la tuerca de la manguera de succión (**P153**) sobre la manguera de succión, vuelva a colocar la manguera de succión sobre la lengüeta de la válvula cheque y apriete la tuerca de la manguera de succión (**P153**).

